

BRUSSO®

American Made

PRECISION HARDWARE

INSTALLATION INSTRUCTIONS FOR KNOBS, HOOKS, AND BOX FEET

Drill a hole that is **X**" in diameter and **Y**" deep. Use adhesive to hold into place. See chart below and each product's tear sheet for reference .

Be sure to try it out in scrap wood first.

Hooks	MC-437	MC-510
Diameter(X)	3/16"	3/8"
Depth(Y)	7/32"	1/4"

Box Feet	JB-423	JB-426	JB-755	MC-444
Diameter(X)	5/16"	1/2"	5/8"	3/8"
Depth(Y)	1/4"	5/16"	5/16"	13/64"

Knobs	MC-422	MC-428	MC-432	MC-434
Diameter(X)	3/16"	3/16"	5/16"	3/8"
Depth(Y)	9/64"	13/64"	1/4"	5/16"